


JAWAR SPS-K INSTALLATION INSTRUCTIONS



17. Cut the last pipe, so that it outstands 15cm over the cover plate (the bell part should be cut off). Mount the pipe. Seal the joint between the cover plate and the formwork, using roofing silicone. Mount the end cone stabilizer 7cm below the top of the last pipe. Tighten the adjustment on the stabilizer. Put silicone on the top of the pipe. Mount the end cone, until you hear a click.



16. Before the last block is mounted, cut two openings size 80x200mm for air checks (in opposite walls of the block). Mount the block and a formwork on it, using mortar. Next, mount the cover plate or make it yourself.


15. Mount next blocks and pipes until the designed chimney height is reached.

14. Mount the cut pipe with stabilizer. Mount the gas connection.




13. Mount the second cut block using mortar.

12. Remove the pipe and the last block. Cut an opening according to marking in the pipe.



13. Put silicone into the bell end of the last mounted pipe.

11. Use technical documentation to determine the height of the gas connection. Cut an opening size 160x260mm in block(s) on the determined height of the gas connection.




Mount the first cut block using the mortar. Put the next cut block on it without the mortar. Put a pipe into it without using silicone. Mark the gas connection on the pipe, in axis with the cut opening of blocks.



10. Put silicone into the bell end of the pipe. Mount next two blocks. Use the stencil and make sure that the grout will not block the air channels.




9. Clean the bell end of the tee and put silicone into it. Mount a stabilizer onto the smooth end of the cut pipe. Fix it so that it will not move. Mount the pipe onto the tee. Remove excess silicone.




Attention!!! Mount stabilizer on every pipe

8. Measure and cut the first mounted pipe, so that it will not outstand over the third block.




6. Cut an opening in the third block, according to the drawing.



7. Use stencil to put mortar onto the second block and mount the third block. Make sure that mortar excess will not block the air channels.

5. When the condensate tray is dry, put silicone onto the top of it. Next, mount the inspection tee onto it. Clean the excess silicone.

4. Cut an opening 260x330mm in the second block. When the socle is solid, place the second block using a mortar. On the socle place the condensate tray. Attention!!! The condensate tray should be levelled and centered in the block. The condensate outlet should be placed towards the opening in the block. Clean the tray with a moist sponge.





3. Place the first block. Fill the block with concrete to make a chimney socle.


2. Make a water-tight insulation. Remember to consider "0" level.

1. Make a concrete foundation under the planned chimney

Manual installation of cover plate



After finishing the montage, fill in the nameplate and place it in a visible place. Fill out the warranty card.



FOR THE CHIMNEY INSTALLATION WE NEED:



Attention: Before you start installation, read the instruction, check the installation packet content. After finishing installation, plaster the chimney using 1,5cm plaster and mount all the necessary accessories.


General rules of joining ceramic elements:



Clean the pipe edge using a moist sponge



Put the right amount of silicone into the pipe bell.



Correctly joined pipes without excess silicone inside.

air and exhaust connections

